

## MASTER OF MATERIALS





### Captain Cook 42 mm & Golden Horse

Place the watch face down on a protected surface. Double-pin spring bar.



# **STEP 1** REMOVE THE BRACELET 1 Press towards the center. 2 Take out the bracelet.







#### STEP 2 PLACE NEW BRACELET, RICE GRAIN

Bracelet and separate end piece.

Slide the spring bar into the bracelet to connect the elements.

Make sure your bracelet is in the right position before you proceed.





#### STEP 2 PLACE NEW BRACELET, 3 LINK BRACELET

Bracelet and fixed end piece.

Slide the spring bar into the bracelet to connect the elements Make sure your bracelet is in the right position before you proceed.



#### **STEP 3** FIX THE BRACELET

To add, press the spring bar together towards the center. Keep it pressed together. Push in the spring bar simultaneously and shift it into the holes of the case on both sides. Unlash the spring bar.



**STEP 4** CHECK THE ATTACHMENT
A Check that the bracelet is firmly attached!
B The bracelet should be perfectly aligned to the lugs.



The spring bar should be perfectly in place and the end piece should not move.

If you would prefer a watchmaker to change the bracelet for you, please take your watch to your nearest Rado Boutique.



## MASTER OF MATERIALS