

# MASTER OF MATERIALS









STEP 1

Place the watch face down on a protected surface.



### **STEP 2** REMOVING THE STRAP

Push in and simultaneously lift up the spring bar. Remove the nato strap.





### **STEP 3** ADDING A NEW STRAP

Place the watch face down on a protected surface. Position the nato strap with the clasp at 12 o'clock. The anchor should be in the center of the watch. Insert the spring bar into the holes.




# STEP 4

Slide the strap through the loop and pull into place. Adjust the strap to ensure that the watch head is in the middle.



**STEP 5**Check that the nato strap is firmly attached.






### **ADJUSTMENT** FOR SMALLER WRISTS

Remove the watch case from the strap. Use a tool to carefully remove the spring bar which holds the loop in place, see image A.

Remove the loop and reattach the spring bar. Slide the loop back onto the strap and into the position shown, see image B. Slide the watch case back onto the strap.



**RESULT** A WATCH STRAP ADJUSTED FOR SMALLER WRISTS



#### **ADJUSTMENT** FOR LARGER WRISTS

Use a tool to carefully remove the spring bar which holds the loop in place, see image A. Reposition the loop and reattach the spring bar, see image B.



**RESULT** A WATCH STRAP ADJUSTED FOR LARGER WRISTS

If you would prefer a watchmaker to change the straps for you, please take your watch to your nearest Rado Boutique.



## MASTER OF MATERIALS